

## Using Group Call Pickup

You may use your phone to pick up a call ringing on another phone in your pickup group. Your pickup group is programmed by your system administrator.

When using the **Optiguide menu**,

- Press the “**Program/Service**” key.
- Scroll to and select “**Pickup Group?**”
- Begin speaking when the call is connected to you.

When using a **programmed key**,

- Press the “**Pickup Group**” key.
- Begin speaking when the call is connected to you

When using Feature access codes

- Dial \*57 and the call will be connected to you