

## Programming a Repdial Key

You may program a repdial key to quickly dial frequently used numbers or access features.

When using the **Optiguide menu**,

- Press the “**Program/service?**” key.
- Scroll to and select “**Prog. Feature key?**”
- **Press the repdial key** you would like to program.
- Select “**Change key?**”
- Select “**Repdial key?**”
- **Enter the number** to be programmed.
- Scroll to and select “**Exit?**”

To **place a call** using a repdial key, simply **press the key**.

When using a **programmed key**,

- To **place a call** using a repdial key, simply **press the key**.

You must use the Optiguide to program your repdial keys.

When using **Feature Access Codes**

- Dial \*91
- Press the key you wish to program
- Follow the prompts on the Optiguide menu

You may program the second level of a Repdial key by pressing the “Shift” key before pressing the particular repdial key during the programming sequence.

When entering the phone number, don't forget any necessary outside line access codes.

You may use the minus to add a delay of two seconds in your programmed number

